

### **Installation instructions for 2004 MY and newer Steering Wheel badges**

1. Clean the surface of the stock badge and surrounding area thoroughly with rubbing alcohol.
2. Heat the new badge with a hair dryer until it is quite warm (this helps it conform to the slightly concave surface of the stock badge).
3. Strip off the backing that protects the adhesive.
4. Carefully apply the new badge so that is properly aligned. Press it at the center first, then outward around the edges. Press the entire surface firmly to be sure it is properly adhered.